



## **Installation Precaution:**

- 1. Before installation, carefully read the manual and operate according to the content of the manual;
- 2. Installed by qualified electricians;
- 3. To avoid the risk of electric shock, make sure to turn off the power before installation and maintenance;
- 4. Suitable for indoor installation and use (not suitable for damp environments);
- 5. The light source of this lamp is non-replaceable, and once it needs to be replaced (such as at the end of the lamp's lifespan), the entire lamp should be replaced;
- 6. Do not install the lighting fixtures on unstable or unstable ceilings to prevent them from falling;
- 7. Keep this manual properly for future use.

#### **Attention:**


- 1. It is prohibited to touch fingers or other objects with the reflector's light outlet, otherwise it will affect the light output effect!
- 2. When moving lighting fixtures, be careful not to press the panel!






3. If there is any protrusion or protrusion on the back cover of the lamp (as shown in the left figure below), press down with both hands and then release to reset the cover!









# One Assembly of track light connectors

1. Before assembly, ensure that the "conductive switch" is at a 90 ° angle with the connector and that the reversing knob is in the "OFF" state.





Licensed by "WAC" trademark holder - WAC LIGHTING, USA

Chinese Marketing Headquarters : WAC Lighting (Shanghai) Co, Ltd.


Address China factory Address : WAC Lighting (Shanghai) Co, Ltd. : 14,Lane 299, Bi Sheng Road, Shanghai 201204,China

: Manufactured WAC Lighting (Dongguan) Co, Ltd.


: 390, Qingfeng Road, Qingxi Town, Dongguan, Guangdong. Postal code: 523653




Align the protrusion of the track light connector with the groove of the track before assembl.



After installing the guide rail light connector, pull out the steel cable at the upper end of the light fixture and hang the hook on the track or other suitable place. The schematic diagram after installation is as follows.



## Three.Phase change adjustment and lamp removal:



is necessary to set the gear to "OFF", then turn the conductive switch counterclockwise to form a 90 ° angle with the guide rail, and remove the light fixture

"OFF" indicates that the rail connector is not connected to the power supply;

- 1 indicates that the rail connector is connected to the
- 1-phase position of the rail;
- 2 indicates that the rail connector is connected to the 2-phase position of the rail;
- 3 indicates that the rail connector is connected to the
- 3-phase position of the rail.


Licensed by "WAC" trademark holder - WAC LIGHTING, USA


Chinese Marketing Headquarters WAC Lighting (Shanghai) Co, Ltd.

: 14,Lane 299, Bi Sheng Road, Shanghai 201204,China Address China factory : Manufactured WAC Lighting (Dongguan) Co, Ltd. Address




## FOUR.Lamp adjustment:






## Five. Installation of attachments:

## 1. Replace optical accessories



## **Six.Maximum lifting weight:**

- 1. The track system can withstand the maximum weight as shown in the following figure, which includes the weight of the entire suspension system.
- 2. A single adapter can withstand a maximum load of 10kg (apply the load to the adapter according to the normal installation position of the lamp).



Licensed by "WAC" trademark holder - WAC LIGHTING, USA

Chinese Marketing Headquarters : WAC Lighting (Shanghai) Co, Ltd.

Address China factory Address : 14,Lane 299, Bi Sheng Road, Shanghai 201204,China

: Manufactured WAC Lighting (Dongguan) Co, Ltd.

: 390, Qingfeng Road, Qingxi Town, Dongguan, Guangdong. Postal code: 523653